




Aileron installation

step 01




Aileron installation

step 02




Aileron installation

step 03



Aileron installation

step 04



Aileron installation

step 05




Aileron Servo installation

step 06



Aileron Servo installation

step 07




Aileron Servo installation

step 08




Aileron Servo installation

step 09




Aileron Servo installation

step 10




Aileron Servo installation

step 11




Aileron Servo installation

step 12



Aileron Servo installation

step 13



Aileron Servo installation

step 14



Aileron Servo installation


step 15



Aileron Servo installation

step 16

Optional installation




Slats installation


step 17



Slats installation


step 18





Elevator installation



step 21




**THIN
CA**

Elevator installation


step 22





Elevator installation

step 25



Before glue, check alignment

Elevator installation


step 26



THIN
CA

Elevator installation

step 27



THIN
CA

Elevator installation

step 28



Rudder installation

step 29




Rudder installation

step 30




Rudder installation

step 31




Rudder installation

step 32



Rudder servo installation

step 33



Rudder servo installation

step 34



Rudder servo installation

step 35




Rudder servo installation

step 36



Rudder servo installation

step 37




Rudder servo installation

step 38




Rudder servo installation

step 39




Rudder servo installation

step 40



Elevator servo installation

step 42




Elevator servo installation

step 43




Elevator servo installation

step 43




Elevator servo installation

step 44



Elevator servo installation

step 45




Elevator servo installation

step 46



Elevator servo installation

step 47




Elevator servo installation

step 48





Steering servo installation

step 49



Steering servo installation


step 50





Landing Gear installation

step 53



Landing Gear installation

step 54



Landing Gear installation

step 55



Landing Gear installation

step 56



Landing Gear installation


step 57



Landing Gear installation



step 58



Landing Gear installation

step 59



Landing Gear installation

step 60



Landing Gear installation

step 61



Landing Gear installation

step 62



Landing Gear installation

step 63



Landing Gear installation

step 64




Landing Gear installation

step 65




Landing Gear installation

step 66




Rear canopy installation

step 67




Rear canopy installation

step 68





Rear canopy installation

step 69




Aileron extension installation

step 70




30E class



Electric motor version

step 73


30E class



Electric motor version

step 74


30E class



Electric motor version

step 75


30E class



Electric motor version

step 76


50E class



Electric motor version

step 77


50E class



Electric motor version

step 78


50E class



Electric motor version

step 79


50E class



Electric motor version


step 80

50E class




Electric motor version

step 81




Electric motor version



Electric motor version

step 83



Electric motor version


step 84



Electric motor version



step 85



Electric motor version


step 86

Optional installation




Glow version

step 87





Glow version

step 88



Glow version


step 89



Glow version


step 90

Optional installation




Floats installation

step 91



Floats installation

step 92




Floats installation


step 93



Floats installation


step 94





Wing panel installation

step 97



Receiver

Radio installation example

step 98

Decals



step 99



C.G.

step 100